

EQUIPMENT FOR FAME DISTILLATION



96 134 06 63
P.I. Fuente del Jarro
Ciudad de Elda,11
46988 Paterna | Valencia
www.grupovento.com



Over 99,5% purity is reached from an impure fatty acid methyl ester (FAME) coming from the biodiesel fabrication process

WORKING PROCESS


Over 99,5% quality is achieved from an impure mixture of Fatty Acid Methyl Ester (FAME) coming from the biodiesel fabrication process with a purity of 90-94%.

This continuous distillation system is formed by a deareation column, a distillation column and a final foambreaker. It incorporates an evaporator, a set of condensers, cooler of volatile substances, distilled methyl-ester deposit, process and vacuum pumps, and control mechanisms.

The system is mounted in "skid", a metallic structure with all the elements that form the system interconnected.

PROCESS DIAGRAM

ATEX normative compliant



INSTALLATION EXAMPLE

Installation of FAME DISTILACION for INTEGRAL BIOENERGIES SYSTEMS, S.L. in Paiporta (Valencia) with a treatment capacity of 150 Lts/h. (Pilot Plant)





